

Logging In and Out of Vocera

Logging In and Out

Learn about the commands used to log in and log out.



Important: If someone is already logged in to your Vocera device when you receive it, make sure it is you!

If you use a Vocera device while logged in as someone else, people won't be able to contact you. Take a look at the screen on the device to make sure it displays your name. If the screen displays another name, press the Call button and say "Log me out." Then press the Call button again and log in by saying or spelling your name when the Genie prompts you.

Action	Recommended Voice Commands	Alternative Forms
Log in	<i>When prompted by the Genie, say or spell your first and last name.</i>	
Log out	Log me out.	Log out.

If your organization shares Vocera devices, make sure you log out when you are finished using your device. Turning the power off or removing the battery does not log you out—the Genie remembers you are logged in when the device gains power again.

You can log into the system on only one Vocera device at a time. If you try to log in with a second device, the Genie reminds you and asks you to confirm if you still want to log in. When you say Yes, the system logs in your new device and logs out your first Vocera device.